



## Kingston CompactFlash

Products: CF/32, CF/64, CF/128, CF/256, CF/512, CF/1024



Kingston's CF (CompactFlash™) memory cards offer an incredible combination of high storage capacity, fast data transfer rates, and great flexibility. CompactFlash offers the speed of a memory chip and the portability of a floppy, with enhanced capacity, all in the palm of your hand. With CompactFlash capacities ranging from 32MB to 1024MB you are sure to find the capacities you need. Most commonly used in such devices as digital camera's, PDA's and other portable products, Kingston's CompactFlash provides an easy method for quickly downloading and transferring digital files from your computer to the Internet. Our Type I CompactFlash cards can be used in Type II PC Card slots when you use an adapter such as Kingston's CF/ADP. By using a CF reader (Such as Kingston's FCR-U2CF or PCREAD/CF) it is also possible to upload files from your CF card to your computer via the USB or parallel port.



### Optional Accessories

- **FCR-U2CF** - USB CompactFlash media reader
- **FCR-U2CFSM+** - CF/SM USB media reader
- **FCR-U26/I** - 6 in I USB media reader
- **PCREAD/CF** - Parallel Port CF media reader
- **CF/ADP** - CompactFlash Type II PC card adapter

### Product Highlights

#### Features

- Association specification standards
- 1/3 of a full-size PC card
- Plug-and-Play compatible
- Use with available PC Card Type II adapter to make data transfer quick and easy
- Autosleep mode to preserve system battery life
- 3.3V and 5V dual voltage support
- Supports the latest operating systems and supporting software including Macintosh® OS, all Windows® applications 98 and above.

#### Specifications

- 1.43" x 1.68" x .13" (36.4mm x 42.8mm x 3.3mm)
- Endurance: 300,000 cycles per logical sector
- Data retention: 10 Years
- Operating temperature: 0° to 70° C
- Storage temperature: -20° to 85° C
- Operating shock: 1,000Gs
- Average seek time: 10.8ms
- Vibration resistance: 15G
- Warranty: 5 Years

## 256MB CompactFlash Card

CF/256



Acer: n20 Series;

Agfa: ePhoto CL20, ePhoto CL30, ePhoto CL34;

Argus: DC2200 Digital Camera, DC3200 Digital Camera, DC3500 Digital Camera, DC3550 Digital Camera;

ASUS: A620 Pocket PC, MyPal A620BT Pocket PC, MyPal A716 Pocket PC;

Audiovox: PDA1032C Handheld PC;

Canon: CD-200 Digital Printer Series, CD-300 Digital Printer, Digital IXUS, Digital IXUS 300/330, Digital IXUS v, Digital IXUS v3, EOS 10D, EOS 1D, EOS 1Ds, EOS D30, EOS-300D/Digital Rebel/Kiss Digital, EOS-D60, PowerShot 350, PowerShot A10, PowerShot A100, PowerShot A20, PowerShot A200, PowerShot A30, PowerShot A300, PowerShot A310, PowerShot A40, PowerShot A5, PowerShot A5 Zoom, PowerShot A50, PowerShot A70/A60, PowerShot A75, PowerShot A80, PowerShot G1, PowerShot G2, PowerShot G3, PowerShot G5, PowerShot Pro70, PowerShot Pro90 IS, PowerShot S1 IS, PowerShot S10, PowerShot S100 Digital ELPH, PowerShot S110 Digital ELPH, PowerShot S20, PowerShot S200 Digital ELPH, PowerShot S230 Digital ELPH, PowerShot S30/S40, PowerShot S300 Digital ELPH, PowerShot S330 Digital ELPH, PowerShot S400 Digital Elph/ Digital IXUS 400, PowerShot S410, PowerShot S45, PowerShot S50, PowerShot S500;

Casio: Cassiopeia A-20, Cassiopeia BE-300, Cassiopeia E-10, Cassiopeia E-100, Cassiopeia E-105, Cassiopeia E-11, Cassiopeia E-115, Cassiopeia E-125, Cassiopeia E-15, Cassiopeia E-200, Cassiopeia E-500, Cassiopeia E-507, Cassiopeia E-55, GV-10, GV-20 Digital Camera, QV 2000UX, QV 2300UX, QV 2400UX, QV 2800UX, QV 2900UX, QV 3000EX, QV 3500EX, QV 3EX, QV 4000, QV 5500SX, QV 5700, QV 700, QV 7000SX, QV 780, QV 8000SX;

Contax: N Digital;

Dell: Axim X5 Handheld;

Digi-Frame: 10.4 in. LCD Digital Picture Frame DF-1040, 18 in. LCD Digital Picture Frame DF-1800, 3.9 in. LCD Digital Picture Frame DF-390, 5.6 in. LCD Digital Picture Frame DF-560;

Epson: PhotoPC 3000Z, PhotoPC 3100Z, PowerLite 505c, PowerLite 715c, Stylus Photo 785EPX;

Everex: Freestyle 540, Freestyle Associate A10, Freestyle Executive A20, Freestyle Manager A15;

Fuji: FinePix M603, FinePix S1 Pro, FinePix S2 Pro D-SLR, FinePix S20 Pro, FinePix S3 Pro, FinePix S602Z, FinePix S7000 Z;

Fujitsu-Siemens: Pocket LOOX 600, Pocket LOOX 610, Stylistic LT C-500, Stylistic LT P-600F/P-600T, TeamPad 7600;

Gateway: DC-M40/DC-M50 Digital Camera;

Hitachi: HPW 200EC, HPW 600ET, HPW 630ETR;

HP/Compaq: Aero 1520, Aero 1530, Aero 1550, Aero 2110, Aero 2120, Aero 2130, Aero 2150, Aero 2180, Aero 8000, iPAQ h2210, iPAQ h2215, iPAQ h3100 Series, iPAQ h3150, iPAQ h3600 Series, iPAQ h3630, iPAQ h3650, iPAQ h3670, iPAQ h3760/h3765, iPAQ h3800 Series h3835/h3850/h3870, iPAQ h3900 Series h3950/h3970/h3975, iPAQ h5150, iPAQ h5400, iPAQ h5450, iPAQ h5455, iPAQ h5550/h5555, Jornada 420, Jornada 428, Jornada 430se, Jornada 540 Series 540/545/547/548, Jornada 560 Series 564/565/567/568, Jornada 680/680e, Jornada 690/690e, Jornada 710/720, Jornada 820/820e, PhotoSmart 1000 Printer, Photosmart 120, Photosmart 1200, PhotoSmart 215 /

215xi / 215vm, PhotoSmart 315 / 315xi / 315vm, PhotoSmart 318, PhotoSmart 612, PhotoSmart 618 / 618xi, PhotoSmart 715, PhotoSmart 912 / 912xi, PhotoSmart C20 / C20xi, PhotoSmart C200 / C200xi / C200CL, PhotoSmart C30 / C30xi, PhotoSmart C500 / C500xi, PhotoSmart P1000 / P1100 / P1100xi Printers;

IBM: PalmPad 100;

Jenoptik: Jendigital JD 2100 f, Jendigital JD 2100 m, Jendigital JD 2300 z3, Jendigital JD 350, Jendigital JD 5200z3;

JVC America: GC-S1U;

Kodak: DC215 Zoom Millennium 2000 Edition, Digital Science DC120, Digital Science DC200, Digital Science DC220 Zoom Pro Edition, Digital Science DC25, Digital Science DC260 Zoom Pro Edition, EasyShare DC200 Plus, EasyShare DC210 Plus Zoom, EasyShare DC210 Zoom, EasyShare DC215 Zoom, EasyShare DC220 Zoom, EasyShare DC240 Zoom, EasyShare DC240i Zoom, EasyShare DC260 Zoom, EasyShare DC265 Zoom, EasyShare DC280 Zoom, EasyShare DC290 Zoom, EasyShare DC3200, EasyShare DC3400, EasyShare DC3800, EasyShare DC4800, EasyShare DC5000, EasyShare DX3500, EasyShare DX3600, EasyShare DX3900, EasyShare DX4900, mc3 portable printing device, Professional DCS Pro 14n;

Konica Minolta: e-mini M Digital Camera and MP3 Player, Q-M100 / Q-M100 V, Q-M200, Q-mini;

Kyocera: Samurai 2100DG;

Largan: Easy 800;

Leo: FreeStyle K100;

Lexmark: Photo Jetprinter 5770;

LG Electronics: PHENOM Express H220C32, PHENOM H120F08 / H120S08, PHENOM PTRM5/PTRM5F, PHENOM Ultra H120CW16;

Minolta-QMS: 3D 1500, DiIMAGE 2300, DiIMAGE 2330, DiIMAGE 5, DiIMAGE 7, DiIMAGE 7i, DiIMAGE A1, DiIMAGE E201, DiIMAGE EX WIDE 1500, DiIMAGE EX ZOOM 1500, DiIMAGE RD3000, DiIMAGE S304, DiIMAGE S404, DiIMAGE S414;

MiTAC: Mio 558;

Mustek: MDC 3000;

NEC: GT 1150, GT 2150, GT 950, LT 140, LT 150/LT 150Z, LT 154, LT 155, LT 156, LT 84, LT 85, MobilePro 700, MobilePro 750C, MobilePro 780, MobilePro 790, MobilePro 800, MobilePro 880, MT 1050, MT 1055, MT 850, SX 6000, XT 5000;

Nikon: Coolgear Photo Wallet, Coolpix 2000, Coolpix 2100, Coolpix 3100, CoolPix 3500, Coolpix 4300, Coolpix 4500, Coolpix 5700, Coolpix 600, Coolpix 700, Coolpix 775, Coolpix 800, Coolpix 8700, Coolpix 880, Coolpix 885, Coolpix 900, Coolpix 900s, Coolpix 950, Coolpix 950 Millennium, Coolpix 990, Coolpix 995, Coolpix SQ, D100 Digital Camera, D1H, D1X, D2H Digital Camera, Professional Digital SLR Camera D1;

Olympus: C-2500L SLR, C-5050Z Digital Camera, C-8080 Wide Zoom, CAMEDIA C-5060 Wide Zoom, E-1 Digital Camera, E-10 SLR, E-100 RS, E-20 P/N, E-20N Digital Camera, P-200 Printer;

Panasonic: CoolShot KXL-600A, CoolShot KXL-601A, PalmCam PV-DC1080, PalmCam PV-DC1580, PalmCam PV-DC2590, PalmCorder PV-L750, PalmCorder PV-L751, PalmCorder PV-L759, PalmCorder PV-L850, PalmCorder PV-L859, SV-AP10 Series, Toughbook 01 CF-P1 Series;

Pentax: \*ist D Digital Camera, EI 100, EI 200, EI 2000, EI 3000, Optio 230, Optio 330, Optio 330GS, Optio 330RS/430RS, Optio 33L, Optio 430;

Philips/Magnavox: Nino 200/210, Nino 300, Nino 301, Nino 302, Nino 312, Nino 320, Nino 325, Nino 500/510;

Polaroid: PDC 1100, PDC 1300, PDC 2050, PDC 2300Z, PDC 3000, PDC 700, PhotoMAX Digital Camera with MP3 player;

Pretec: DC-1007 Digital Camera, DC1500, DC2000, DC520 Digital Camera, DC530, DC600, DC800;

Psion: netBook Handheld PC, netBook Pro Handheld PC, Series 5, Series 7, WORKABOUT PRO C Handheld PC, WORKABOUT PRO M Handheld PC;

RCA: CDS4100, Lyra A/V RD2780, Lyra RD2201, Lyra RD2204, Lyra2 RD2211;

Reynolds: LifecardCF Holter Recorder;

Ricoh: RDC 100G, RDC i500, RDC i700;

Rozinn: Digital Holter Recorder RZ153;

Samsung: Digimax 130, Digimax 210, Digimax 210se, Digimax 230, Digimax 330, Digimax 340, Digimax 350se, Digimax 410, Infogear, SSC 410N;

Sanyo: DSC-AZ1, DSC-MZ1, VPC SX500, VPC SX550, VPC SX550MD, VPC-AZ3 Digital Camera, VPC-MZ3 Digital Camera, VPC-R1 Digital Camera;

Sharp: Mobilon Tripad PV-6000, Zaurus MI-E1, Zaurus MI-E21, Zaurus MI-E25, Zaurus MI-L1, Zaurus SL-5500, Zaurus SL-5600, Zaurus SL-6000, Zaurus SL-B500, Zaurus SL-C700, Zaurus SL-C750, Zaurus SL-C760, Zaurus SL-C860;

Siemens Nixdorf: SX45;

SiPix: SC-2100 Digital Camera;

Sony: CLIE PEG-NX73V, CLIE PEG-NX80V, DSC-F828 Digital Camera;

Spacelabs Medical: Burdick Compact Holter Monitor Model 92513;

Toshiba: Genio e550, e550/MD, Pocket PC e570, Pocket PC e740 Series, Pocket PC e750, Pocket PC e755, Pocket PC e800/e800BT/e800 WiFi;

UMAX: AstraPix 490, AstraPix 540;

Vadem: Clio C-1000, Clio C-1050;

VideoChip: Photo Wallet;

Vivitar: ViviCam 2800, ViviCam 3100, ViviCam 3200, ViviCam 3305, ViviCam 3615, ViviCam 3620, ViviCam 3630, ViviCam 3655, ViviCam 3665, ViviCam 3725, ViviCam 3735;

Yashica: FineCam 3300, Samurai 1300DG, Samurai 2100DG.